



Air-conditioner Control System Advanced Touch Controller

MODEL

AT-50B

Instruction Book



Before using the controller, read this Instruction Book carefully to ensure proper operation.

Retain this Instruction Book for future reference.

Make sure that this manual as well as the Installation Manual are passed on to any future air condition system users.

To ensure safety and proper operation of the unit, the unit should only be installed by qualified personnel.

Safety Precautions	2
Function List	4
Names and Functions of Controller Components.....	6
Screen Configuration [HOME screen]	8
Buttons [HOME screen].....	10
Icon Displays [HOME screen].....	12
Basic Operations	16
Screen selection.....	16
Group selection	17
Operation Screen (GROUP screen)	18
Operating the Air conditioning unit group • Air To Water (PWFY) group	18
ON/OFF operation	18
Mode.....	18
Temperature setting.....	21
Interlocked ventilation units(LOSSNAY)/Fan speed/Air direction/Louver settings	23
Disable-Scheduled-Operation button	24
Operating the LOSSNAY group.....	24
Mode.....	24
Fan speed setting	24
Operating the general equipment group.....	24
ON/OFF operation	24
Multiple group selection screen	25
Disabling functions	25
Menu Screen	26
Usage - Main Menu Settings	28
Operation Setting	28
Restriction Settings	44
Control Panel.....	52
System Management	59
Maintenance	64
Touch Panel Cleaning screen.....	64
Troubleshooting	65

Safety Precautions

- Thoroughly read the following safety precautions prior to installation.
- Observe the following precautions to ensure safety.

 WARNING	Indicates a risk of death or serious injury.
 CAUTION	Indicates a risk of serious injury or structural damage.

● Nomenclature



(Prohibited actions)



(Do not touch)



(No water)



(No wet hands)



(Electric shock hazards)



(Injury hazards)



(Important actions)

- After reading this manual, pass it on to the end user to retain for future reference.
- Keep this manual for future reference and refer to it as necessary. This manual should be made available to those who repair or relocate the controller. Make sure that the manual is passed on to any future AT-50B users.

All electric work must be performed by qualified personnel.

General precautions

WARNING

Do not install the unit in a place where large amounts of oil, steam, organic solvents, or corrosive gases, such as sulfuric gas, are present or where acidic/alkaline solutions or sprays are used frequently. These substances can compromise the performance of the unit or cause certain components of the unit to corrode, which can result in electric shock, malfunctions, smoke, or fire.



To reduce the risk of shorting, current leakage, electric shock, malfunctions, smoke, or fire, do not wash the controller with water or any other liquid.



To reduce the risk of electric shock, malfunctions, smoke or fire, do not operate the switches/buttons or touch other electrical parts with wet hands.



To reduce the risk of injury or electric shock, before spraying a chemical around the controller, stop the operation and cover the controller.



To reduce the risk of injury or electric shock, stop the operation and switch off the power supply before cleaning, maintaining, or inspecting the controller.



Properly install all required covers to keep moisture and dust out of the controller. Dust accumulation and water can cause electric shock, smoke, or fire.



CAUTION

To reduce the risk of fire or explosion, do not place flammable materials or use flammable sprays around the controller.



To reduce the risk of damage to the controller, do not directly spray insecticide or other flammable sprays on the controller.



To reduce the risk of electric shock or malfunctions, do not touch the touch panel, switches, or buttons with a pointy or sharp object.



To reduce the risk of injury and electric shock, avoid contact with sharp edges of certain parts.



To avoid injury from broken glass, do not apply excessive force on the glass parts.



To reduce the risk of injury, wear protective gear when working on the controller.



Precautions during installation

WARNING

Do not install the controller where there is a risk of leaking flammable gas. If flammable gas accumulates around the controller, it may ignite and cause a fire or explosion.



Properly dispose of the packing materials. Plastic bags pose suffocation hazard to children.



Precautions for moving or repairing the controller

⚠ WARNING

The controller should be repaired or moved only by qualified personnel. Do not disassemble or modify the controller.
Improper installation or repair may cause injury, electric shock, or fire.



⚠ CAUTION

To reduce the risk of shorting, electric shock, fire, or malfunction, do not touch the circuit board with tools or with your hands, and do not allow dust to accumulate on the circuit board.



Additional precautions

To avoid damage to the controller, use appropriate tools to install, inspect, or repair the controller.

AT-50B is designed for exclusive use with the Building Management System by Mitsubishi Electric. The use of this controller for with other systems or for other purposes may cause malfunctions.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

To avoid damage to the controller, do not overtighten the screws.

To avoid discoloration, do not use benzene, thinner, or chemical rag to clean the controller. To clean the controller, wipe with a soft cloth soaked in mild detergent that is diluted with an appropriate amount of water, and wipe down with a wet cloth followed by a dry cloth. Do not use the detergent straight.

To avoid damage to the controller, provide protection against static electricity.

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Function List

The table below summarizes the functions that are available on the AT-50B.

Refer to the pages listed for details.

Function		Description	Page
Unit Operation	ON/OFF operation	Switches the ON/OFF operation of the units such as air conditioning units. The LED on the Collective ON/OFF button will light up when one or more units are in operation and off when all units are stopped.	18
	Mode *1	Switches the mode as follows for each group or all groups. Air conditioning unit group: Cool/Dry/Fan/Auto/Heat LOSSNAY group: Bypass/Heat recovery/Auto Air To Water (PWFY) group: Heating/Heating ECO/Hot Water/ Anti-freeze/Cooling	18
	Set Temperature *1	Sets the set temperature for each group or all groups.	21
	Fan Speed *1	Adjusts the fan speed for each group or all groups.	23
	Air Direction *1	Adjusts the air direction for each group or all groups.	23
	Louver *1	Enables/disables the louver for each group or all groups.	23
	ON/OFF operation for interlocked ventilation *1	The ON/OFF operation of the interlocked ventilation unit is interlocked with the ON/OFF operation of the air conditioning unit. The interlocked ventilation units can be independently operated for ON (High/Low)/OFF for each group or all groups. (When the ventilation unit is interlocked with the air conditioning unit, the ventilation mode cannot be used.)	23
Time and Schedule	Collective Operation	The following functions can be collectively executed on multiple groups: Setback, Schedule, Mode, Temperature Correction, RC Prohibition.	20 40
	Date and Time	Sets the date, time, and display formats. The current time will appear at the top right corner of the HOME screen.	28
	Weekly/One-day schedule	- Allows the user to set the weekly schedule for each group. - Maximum of 16 events can be scheduled for each day. - The types of actions that can be scheduled are as follows: ON/OFF, Mode, Set Temperature, Fan Speed, Air Direction, and Prohibit Remote Controller Operation. - Maximum of 12 patterns can be configured for the weekly schedule, and 5 for one-day schedule. - Two types of weekly schedules (Summer/Winter) can be set. - One-day schedule overrides the weekly schedule.	30
	Setback Control	This function helps keep the indoor temperature in the temperature range while the units are stopped and during the time this function is effective.	37
	Disabling scheduled operation	Scheduled operation can be temporarily disabled. This setting must be set to OFF to run scheduled operation.	24
System Management	System-Changeover	Automatically switches the entire system (all indoor units that are connected to the same outdoor units) to cooling or heating by periodically monitoring the room temperature and the preset temperature of each group and determining the best operation mode. The System-Changeover function is not available for the following types of products: Simultaneous cooling/heating units (with automatic mode change function), Mr. SLIM®, LOSSNAY, and DIDO controller.	61

*1: Available functions vary depending on the unit type. Only the functions that are supported by the connected units can be controlled from the AT-50B.

Function		Description	Page
Restriction Settings	Lock Buttons	Locks the following buttons: Collective ON/OFF, F1, F2, and Main Menu screen buttons. Locks the following functions: ON/OFF, Mode, Set Temperature, Fan Speed, and Schedule ON/OFF.	11 25 44
	Set Temperature Range Limit	Limits the available temperature range for the local remote controllers (each group or all groups).	46
	Prohibit Remote Controller	Prohibits access to the ON/OFF, Mode, Set Temperature, Maintenance Sign Reset, Air Direction, and Fan Speed settings from the local remote controllers, and also deactivates Timer (Schedule) settings from the local remote controllers (collectively or by group).	48
	Operation Mode Selection Limit	When set as the main controller, operation of the following modes with the local remote controllers can be prohibited. No Cooling Operation: Cool, Dry, and Auto cannot be chosen. No Heating Operation: Heat and Auto cannot be chosen. No Heating/Cooling: Cool, Dry, Heat, and Auto cannot be chosen.	50
Basic Settings	Display Format	Selects the display formats for the following items: Display language, temperature unit, room temperature, display or non-display of Cool/Heat mode icons (during Auto mode), backlight timer, and group names.	52
	Function Key Setting	The F1 button and the F2 button can be set as a run button of the following collective operation: Setback, Schedule, Mode, Temperature Correction, Remote Controller Prohibition.	56
	HOME screen Group Icon Setting	When the group icon is touched, the action differs depending on the group icon setting. Default is set to the Group icon setting 2. Group icon setting 1: Turns ON/OFF the units in the group whose group icon is touched. Group icon setting 2: Displays the check mark when group icon is touched. Touch the group icons of the groups to be operated, and then touch the "Operate" button to move to the GROUP screen. Multiple groups can be selected. Use this mode when operating the multiple groups collectively. Group icon setting 3: Directly moves to the GROUP screen of the group whose group icon is touched.	43
	Volume Control	Sets the sound volume and screen brightness.	57
Maintenance	Error	If an error occurs on the AT-50B controller or the units and controllers it controls, the LED on the Collective ON/OFF button will blink. If an error occurs on the indoor or LOSSNAY units, Δ will appear on the corresponding group icon on the HOME screen. The error code can be verified and reset on the Status List screen.	59
	Maintenance Sign	Filter icon will appear on the HOME screen when the filter is due for cleaning. The icon can be removed from the Status List screen.	60
	Touch Panel Cleaning mode	Disables the touch panel to allow the user to clean the panel.	64
	Touch Panel Calibration mode	Calibrates the touch panel if the touch panel does not respond correctly when touched.	58
Miscellaneous	External input	Receives input signals from external devices and start/stop all groups of units or permit/prohibit operations from the local remote controllers. Requires cable connections.	
	External output	Outputs the operation status of the units (ON/OFF) or error signals to external devices collectively, using contact signals. Requires cable connections.	

Names and Functions of Controller Components

Product features

The AT-50B described in this manual is a centralized controller with color LCD touch panel for air conditioning units, LOSSNAY, Air To Water (PWFY)*, and general equipment using the Mitsubishi Electric DIDO controller (PAC-YG66DCA).

AT-50B can control up to 50 units/50 groups. *1

AT-50B controls and monitors the air conditioning units of each group. AT-50B also can control detailed scheduling and prohibits the local remote controller operation in each room (group), which may lead to energy savings.

Basic operations are accessed through the AT-50B touch panel. ON/OFF, F1, and F2 operations that control air conditioning units collectively are accessed by using buttons next to the touch panel.

AT-50B display screen consists of three types, corresponding to the usage.

- HOME screen : Monitoring screen to monitor the operation status of the units (described in this Instruction Book)
- Main Menu screen : Setting screen to set the functions such as schedule settings (described in this Instruction Book)
- Maintenance screen : Initial setting screen to set the basic systems such as group settings (described in the Installation Manual)

* 1 Group: minimum unit to be controlled by AT-50B

A group consists of units (16 units maximum).

* "Booster unit" and "Water HEX unit" are referred to as "Air To Water (PWFY)".

* AHC (Advanced HVAC CONTROLLER) cannot be controlled from AT-50B.



Buttons ②, ③, and ④ have indicators on the top.

Touch panel/Buttons

① Display/Touch panel

AT-50B features a 5" color LCD touch panel. Touch panel displays the operation status of the units. Function settings such as week schedule settings are accessed through the touch panel. The backlight lights up when the panel is touched, and lights off after certain period of time. The backlight will remain lit as long as an error exists.

② **Collective ON/OFF** button *1

The **Collective ON/OFF** button enables the collective ON/OFF function that allows the user to turn on/off the air conditioning units, LOSSNAY, DIDO controllers, and Air To Water (PWFY) units in all groups collectively.

The indicator corresponds to the operation status of controlled units.

Unlit : Indicates that all units are stopped.

Lit : Indicates that one or more units are in operation.

Blink : Indicates that an error is occurring.

③ **Function 1** button (F1), ④ **Function 2** button (F2) *1 *2

Desired functions from the following list can be assigned to the F1 and F2 buttons.

(Setback/Schedule/Mode/Temperature Correction/Remote Controller Prohibition)

The functions to assign to these buttons can be selected from the Function Key Setting on the Control Panel.

The indicator on the buttons indicates the enabled/disabled status of the function.

Unlit : The assigned function is disabled.

Lit : The assigned function is enabled.

The indicators on the F1 and F2 buttons will be lit or unlit when the functions that are assigned to the F1 and F2 buttons are enabled or disabled from the Collective Operation panel.

⑤ **Power indicator**

The power indicator lights up when the power to AT-50B is turned on.

Unlit : Power OFF

Lit : Power ON

*1 When the button is pressed while the operation is prohibited, the LED will blink twice.

*2 Buttons ②, ③, and ④ are available only on the HOME screen.

Screen Configuration [HOME screen]

1. How to switch the HOME screen

Touch tabs to change the display format.

-  : Displays the GRID screen.
-  : Displays the GRID (zoom-out) screen.
-  : Displays the GRID (zoom-in) screen.
-  : Displays the LIST screen.
-  : Displays the GROUP screen.

2. How to move to the Main Menu screen

-  : Displays the Main Menu screen.

3. How to move to the Maintenance screen


Refer to the Installation Manual.

GRID screen

Zoom-out screen



To the GRID
(zoom-in) screen



To the GRID
(zoom-out) screen

Zoom-in screen



HOME screen

GROUP screen




To the LIST screen

To the GROUP screen

LIST screen



[Main Menu screen]




Buttons [HOME screen]

HOME screen


GRID (zoom-out) screen

Displays the operation status of all groups.
The button layout ⑥ varies with the number of the registered groups.



LIST screen

Displays the detailed operation status of each group with group name. (5 groups on 10 pages maximum)



GRID (zoom-in) screen

Displays the detailed operation status of each group. (10 groups on 5 pages maximum)




GROUP screen

Displays the detailed operation status of each group. Sets group operations.
(When the air conditioning units or Air To Water (PWFY) units are controlled)



Note: Display ⑨ and ⑩ vary depending on the Group icon setting.
Refer to P17 "Group icon setting" for details.
Sample displays above are for default setting: Group icon setting 2.

Group icon setting 1	
Group icon setting 2	
Group icon setting 3	



① GRID screen button

Displays the GRID screen.

② LIST screen button

Displays the LIST screen.

③ GROUP screen button

Displays the GROUP screen.

④ Main Menu screen button

Displays the Main Menu screen.

⑤ Operation lock button

Locks or unlocks the buttons on the AT-50B. Press and hold the button for two seconds to lock or unlock the buttons. The locked/unlocked status icon will appear on the buttons.

 : Locked  : Unlocked

A password may be required to unlock certain buttons. Select the buttons to be locked from the Lock Buttons (Refer to P44.) on the Main Menu. If no items have been selected, the operation lock button will not appear on the screen.

⑥ Group icon (operation status display) button

Operation differs depending on the group icon setting.

Group icon setting 1

Turns ON/OFF the units in the group whose group icon is touched.

Group icon setting 2

Switches the group icon between Selected (checked) and Deselected (unchecked). (Default) Displays the check mark when group icon is touched.

Group icon setting 3

Directly moves to the GROUP screen of the group whose group icon is touched.

⑦ Access-the-Collective-Operation-panel button

Press this button to bring up the Collective Operation panel. (Refer to P20 for information about the Collective Operation panel.)

⑧ GRID (zoom-out/zoom-in) screen button

 : Displays the zoom-out screen.
 : Displays the zoom-in screen.

⑨ Select-All button

Selects/Deselects groups collectively. Adds check marks to all selected icons.

⑩ Move-to-the-selected-group button

Moves to the GROUP screen of the selected group. Moves to the multiple group selection screen when multiple groups are selected. Refer to P25 "Multiple group selection screen" for details.

⑪ Page button

Flips through pages.

⑫ Display selection button

Shows/Hides the display for the information below.

- Set temperature
- Scheduled operation is enabled.

⑬ Group-switching button

Switches the group to be displayed.

⑭ Mode button

Switches the operation mode of the air conditioning units, LOSSNAY, and Air To Water (PWFY) units.

⑮ Set temperature button

Adjusts the set temperature by using the + and – buttons. Set temperature appears above the button.

⑯ Disable-Scheduled-Operation button

Use this button to temporarily disable the scheduled operation on the display. The indicator on the button will remain lit when the function is enabled. The scheduled operation will not be run when the icon  is displayed.

⑰ Interlocked ventilation (LOSSNAY)/Air direction/Fan speed/Louver setting button

Displays the popup window of interlocked ventilation (LOSSNAY)/air direction/fan speed/louver setting screen.

* Refer to P23 "Interlocked ventilation units (LOSSNAY)/Fan speed/Air direction/Louver settings" for the popup window.

⑱ ON/OFF button

Changes the operation to ON/OFF.

⑲ Set temperature button (Auto (dual set point) mode)

When the cooling and heating set temperatures are displayed above the button, touching the button will display the popup window to adjust the set temperatures for the Auto (dual set point) mode. Refer to P21 "Temperature setting" for details.

⑳ Fan speed selection button

Switches LOSSNAY fan speed between Low and High.

① Current time

Displays the current time.

② Current page/Total pages

Displays the current page/total page number.

Note: Depending on the units to be controlled and AT-50B settings, available button operations and displays vary.
: While the  icon is displayed on the button, the operation is locked.

Icon Displays [HOME screen]

(1) GRID (zoom-out) screen



[ON (BG Color: blue)]

Group No.



- Check Water sign**
- Filter sign*
- Check mark

* For Air conditioning units
** For Air To Water (PWFY) units

[OFF (BG Color: black)]



[Error (BG Color: yellow)]



Error display
Communication error at startup

(2) GRID (zoom-in) screen



[Air conditioning unit group]

[ON (BG Color: blue)]

- Check mark
- ON/OFF operation prohibition

Group No.



- Schedule (enable/disable)
- Room temperature
- Interlocked ventilation (LOSSNAY) operation

[OFF (BG Color: black)]




[Air To Water (PWFY) group]

[ON (BG Color: blue)]

- Check mark
- ON/OFF operation prohibition

Air To Water (PWFY) mark

Group No.



- Schedule (enable/disable)
- Water temperature
- Air To Water (PWFY) icon

[OFF (BG Color: black)]



[Error (BG Color: yellow)]

[Air conditioning unit/LOSSNAY/
General equipment group]



Error display

[LOSSNAY group]

[ON (BG Color: blue)]

- Filter sign:
- LOSSNAY icon



Schedule (enable/disable)

[OFF (BG Color: black)]



[General equipment group]

[ON (BG Color: blue)]



Schedule (enable/disable)

General equipment icon

[OFF (BG Color: black)]



Error:

Displays when an error occurs.

Startup (communication) error:

Displays as well as the error display when a startup (communication) error occurs.

Filter sign:

Displays when filter needs maintenance.

During scheduled operation:

Displays .

When the Disable-Scheduled-Operation button is enabled or Timer (Schedule) execution is prohibited: Displays .

Room temperature:


Displays the current room temperature. The displayed temperature will blink when the room temperature is at or above 40 °C (104 °F) (39 °C (102 °F) on some models), or at or below 0 °C (32 °F) (8 °C (46 °F) on some models).

*Temperatures will be displayed in 1 °C increments on the GRID (Zoom-in) screen and on the LIST screen, even if the temperature is set to appear in 0.5 °C increments.


(3) LIST screen





[Air conditioning unit group]



Display selection button




* When the temperature offset function is enabled, the temperature will appear in the green outline font.






** Interlocked LOSSNAY does not appear during operation.



Display selection button





[Air To Water (PWFY) group]



[LOSSNAY group]




[General equipment group]



[Error (BG Color: yellow)]

[Air conditioning unit/LOSSNAY/General equipment group]



Water temperature:

Display ranges 0-93°C (32-199°F). When the temperature is beyond the range, 0°C (32°F) or 93°C (199°F) will blink on the display. When multiple Air To Water (PWFY) units are registered to a group, current water temperature on the main Air To Water (PWFY) unit is displayed.

Interlocked ventilation (LOSSNAY):

Displays  when there are ventilation units interlocked with the air conditioning (indoor) units in the group. Icon color indicates the operation status (Blue: ON, Black: OFF).


General equipment icon:

Displays the general equipment type.

Icon Displays [HOME screen]

GROUP screen

[Air conditioning unit group • Air To Water (PWFY) group]




Temperature Correction



Auto (dual set point) mode



While the unit is stopped



*: Displayed only on air conditioning unit groups and when the selected unit supports the function
 **: Displayed only on Air To Water (PWFY) groups

Error: Displays  when an error occurs.

Startup (communication) error:

Displays  as well as the error display when a startup (communication) error occurs.

Filter sign: Displays  when filter needs maintenance.

During scheduled operation: Displays .

Energy saving:  will appear on the screen while energy-save control is being performed. (depending on the indoor unit model)

When the Disable-Scheduled-Operation button is enabled or Timer (Schedule) execution is prohibited: Displays .


Room temperature:

Displays the current room temperature. The displayed temperature will blink when the room temperature is at or above 40 °C (104 °F) (39 °C (102 °F) on some models), or at or below 0 °C (32 °F) (8 °C (46 °F) on some models). When multiple air conditioning units (indoor units) are registered to a group, current indoor temperature on the main indoor unit is displayed.

Note : While the  icon is displayed on the button, the operation is locked.

[LOSSNAY group]

During operation



Fan speed display

While the unit is stopped




[General equipment group]

During operation



General equipment icon

While the unit is stopped



Water temperature:

Display ranges 0-93°C (32-199°F). When the temperature is beyond the range, 0°C (32°F) or 93°C (199°F) will blink on the display. When multiple Air To Water (PWFY) units are registered to a group, current water temperature on the main Air To Water (PWFY) unit is displayed.

When the Temperature Correction function is enabled:

When the Temperature Correction function is enabled, the corrected temperature will appear in the green outline font.

Interlocked ventilation (LOSSNAY):

Displays the operation status of the ventilation that is interlocked with the air conditioning (indoor) units.



General equipment icon:

Displays the general equipment type.

Basic Operations

Screen selection

GRID (zoom-out) screen appears at the initial startup.
Select the desired screen.



Group selection

- **Group icon setting 1, 2, 3**

When the group icon ① is touched, the action differs depending on the group icon setting. Three different group icon settings are available as shown below, and default is set to Group icon setting 2. Refer to P43 for changing the group icon setting.

- **Group icon setting 2: appears in the area marked ②. Allows the user to select groups to be operated. Moves to the GROUP screen.**

Touch the group icon ① to select the group to be operated. Groups can be selected on the GRID or the LIST screens.
Touch the group icon ① to switch between displaying check marks (selected) and hiding check marks (deselected). Touch ③ to select all groups.
Touch the group icons of the groups to be operated, and then touch  ② to move to the GROUP screen.

- The number of selected groups = 1 : The selected group appears on the GROUP screen.
Refer to P18 “GROUP screen” for details.
- The number of selected groups > 1 : The Multiple group selection screen appears.
(The selected groups can be operated collectively.)
Refer to P25 “Multiple group selection screen” for details.

- **Group icon setting 1: appears in the area marked ②. Stops or starts the operation of the air conditioning units through group icon ①.**

* **ON/OFF operation lock **
When AT-50B restricts its own ON/OFF operation, the icon above will appear. The ON/OFF operation will be disabled.

* **During receiving the external input signal**
The ON/OFF button cannot be operated in the following situations.

- When “Emergency Stop (Level signal)” is displayed
- When the external input setting is “ON/OFF (Level signal)”



When the group icon button is set to the Group icon setting 1



The button cannot be operated.

- **Group icon setting 3: Nothing appears in the area marked ②. Moves to the GROUP screen by touching the group icon ①.**

Basic Operations

Operation Screen (GROUP screen)

Operating the air conditioning unit group • Air To Water (PWFY) group

Basic operations (GROUP screen)



ON/OFF operation

Touching ③ allows the indoor units in the displayed group to start/stop.

When interlocked ventilation units (LOSSNAY) are connected, the ventilation units work in conjunction with indoor units. ON: OFF:

[Green]

[Black]

Mode (useable only while the unit is in operation)

Touch ② to access the modes as follows. The selected mode will appear in the area labeled ①.

Air conditioning unit group: Cool/Dry/Fan/Auto*¹/Heat

Air To Water (PWFY) group: Heating/Heating ECO/Hot Water/Anti-freeze/Cooling

*¹ Depending on the indoor unit model, either one or two set temperatures (single or dual set point(s)) can be set for Auto mode.

Air conditioning unit group




*Refer to P53 for Auto mode cooling/heating settings.

*To operate an indoor unit in the heating (cooling) mode while the indoor unit is already operating in the opposite mode, the operation mode cannot be changed until all of the indoor units operate in the same mode or stop. In this case, the mode ① will blink.

*Available mode varies depending on the model. Modes that are unavailable do not appear.

*The operation mode which is restricted by this controller or other controllers cannot be selected.


Air To Water (PWFY) group



Auto (dual set point) mode:

When the operation mode is set to the Auto (dual set point) mode, two set temperatures (one each for cooling and heating) can be set. Depending on the room temperature, indoor unit will automatically operate in either the cooling or heating mode and keep the room temperature within the preset range.

The set temperatures that are specified for the Cool/Dry mode and the Heat mode will be used to automatically control the room temperature to stay within the set temperatures. This mode is especially effective during the in-between seasons, when the temperature difference between the highest and the lowest is large and both heating and cooling modes are used within the same day.




Collective Operation Panel



This panel has the functions that can be executed collectively. (Setback, Schedule, Mode, Temperature Correction, RC Prohibition)

Touching the  icon at the left bottom of the icon on the GRID or the LIST screen will bring up the Collective Operation panel. Each button has an indicator and the function name.

The indicators on the buttons show which functions are assigned to which buttons.




• Before using the Collective Operation buttons, the groups to execute collective settings on must be selected, and the parameters must be set from Main Menu>Operation Setting>Collective Operation Setting.

• If  appears on an icon of a given function, the function is not available.

Performing Collective Operation

- ① On the GRID or the LIST screen, touch the button that brings up the Collective Operation panel.
- ② Select the Collective Operation button on the Collective Operation panel.
- ③ Press OK on the Collective Operation panel.
(Go to ④ if Setback or Mode was selected. Otherwise, the setting is complete.)
- ④ If Setback or Mode was selected, take the following steps.

When Setback is selected




Select the desired item, and touch OK.

- **Scheduled:** Scheduled operation is enabled. The units will operate according to the Setback Control settings. (P37)
- **Unscheduled:** Scheduled operation is disabled. The units will operate according to the Collective Operation settings (Setback). (P41)
- **OFF:** The Setback function will not be executed.

* Regardless of how the above settings are made, the Setback function will not be executed while the unit is in operation.

When Mode is selected



- Touch OK on the popup window.
- Select a mode on the window that will appear.
- Touch OK.

* A blinking indicator on a button indicates that the function that corresponds to the button cannot be collectively executed. Check the settings for the "Collective Operation Setting."

Basic Operations

Checking the status of the collective operation functions

- ① On the GRID or the LIST screen, touch the button that brings up the Collective Operation panel.
- ② Check the color of the indicator on the Collective Operation button.

 (Yellow) : The function is enabled.

 (Gray) : The function is disabled.

Checking the function button settings

- ① On the GRID or the LIST screen, touch the button that brings up the Collective Operation panel.
- ② Check what it says on the indicator on the Collective Operation buttons.

 **F1** : The function is assigned to the F1 button.

 **F2** : The function is assigned to the F2 button.

 : The function is not assigned to the F1 or F2 button.

Temperature setting (useable only while the unit is in operation)

Touch   to adjust the temperature setting.


During the Auto (dual set point) mode

- To change the cooling and heating set temperatures for Auto (dual set point) mode

Touch the set temperature button to display the screen to set the cooling and heating set temperatures.



Touch (1) to set the cooling and heating set temperatures. Then, touch the OK button (2).



Set temperature range

Air conditioning unit group

(* When Fan mode is selected, the temperature setting cannot be made.)

Operation mode	Set temperature range
Cool/Dry	19°C–35°C/67°F–95°F ^{*1}
Heat	4.5°C–28°C/40°F–83°F ^{*1}
Auto (single set point)	19°C–28°C/67°F–83°F ^{*1,2}
Auto (dual set points)	Cool: Same as the set temperature range for Cool mode Heat: Same as the set temperature range for Heat mode ^{*2,3,4}
Fan	Not settable

^{*1} The settable temperature ranges vary, depending on the indoor unit model.

^{*2} The set temperature for Auto mode (either single or dual set point(s)) will appear depending on the indoor unit model.

^{*3} The same values are used for the set temperature for Cool/Dry mode and the cooling set temperature for Auto mode (dual set points). Likewise, the same values are used for the set temperature for Heat mode and the heating set temperature for Auto mode (dual set points).

^{*4} The cooling and heating set temperatures can be set under the following conditions.

- The cooling set temperature is greater than the heating set temperature.
- The difference between the cooling and heating set temperatures is equal or greater than the minimum temperature difference that varies with the indoor unit model.

Air To Water (PWFY) groups

* Available set temperature range varies depending on the mode or model.

The temperature can be set within the following range.

** The temperature is controlled automatically in the Heating ECO mode. The user cannot change the temperature settings.

[Booster unit]	
Heating	: 30°C–50°C/87°F–122°F
Heating ECO**	: 30°C–45°C/87°F–113°F
Hot Water	: 30°C–70°C/87°F–158°F
Anti-freeze	: 10°C–45°C/50°F–113°F
Cooling	: Invalid


[Water HEX unit]	
Heating	: 30°C–45°C/87°F–113°F
Heating ECO**	: 30°C–45°C/87°F–113°F
Hot Water	: Invalid
Anti-freeze	: 10°C–45°C/50°F–113°F
Cooling	: 10°C–30°C/50°F–87°F

Interlocked ventilation units (LOSSNAY)/ Fan speed/Air direction/Louver settings

(for air conditioning unit groups only)



Touch ④ to show the Interlocked ventilation units (LOSSNAY)/Fan speed/Air direction/Louver settings screen.



A Interlocked ventilation units (LOSSNAY)

* This setting appears only when interlocked ventilation unit is connected.



B Fan speed (useable only while the unit is in operation)

* This setting appears only when the unit has this function.
* Available fan speed varies depending on the model.



C Air direction (useable only while the unit is in operation)

* This setting appears only when the unit has this function.
* Available air direction varies depending on the model.



D Louver (useable only while the unit is in operation)

* This setting appears only when the unit has this function.



After completing the settings, touch the **OK** button.

Basic Operations

Disable-Scheduled-Operation button



The Disable-Scheduled-Operation function is ON.



The Disable-Scheduled-Operation function is OFF.

Use button ⑤ (P18) to temporarily disable the scheduled operation.


When the function is enabled, the indicator on button ⑤ will light up in yellow.

When this function is enabled, the icon  will appear on the screen, and the scheduled operation will not run.

The Timer (Schedule) execution is prohibited when this function is disabled and the icon  is displayed.

Operating the LOSSNAY group

Displays that are not marked by numbers on the screen are the same as those on the air conditioning unit group screen.



Mode

Touch (1) to access the modes in the order "Bypass, Heat recovery, Auto."

The selected mode will appear in the area marked (2).



*Available mode varies depending on the model.
Modes that are unavailable do not appear.

Fan speed setting

Touch (3) to access the fan speeds in the order "Low, High."

The selected fan speed will appear in the area marked (4).

Operating the general equipment group

Displays that are not marked by numbers on the screen are the same as those on the air conditioning unit group screen.



Displays the general equipment type.

*When changing icons, refer to the Installation Manual.

ON/OFF operation



- When the general equipment is turned on, the output contact of DIDO controller (PAC-YG66DCA) also turns on.
- When the general equipment is turned off, the output contact of DIDO controller (PAC-YG66DCA) also turns off.

Multiple group selection screen

* To operate the air conditioning unit group

Allows the user to collectively operate all groups that are selected on the GRID or LIST screen.

When selected groups include two or more unit types, select the unit type to be operated. Then, the target group will be the selected unit group.



Check the selected groups. Touch (1) to show the selected group confirmation screen.

Disabling functions

Lock Buttons

When AT-50B locks its own functions for ON/OFF, Mode, Set Temperature, Fan speed, or Disable-Scheduled-Operation button, the icon above will appear on the corresponding buttons, and the functions will be disabled.


When the ON/OFF button is locked, the Collective ON/OFF button will be enabled.

Example) ON/OFF button locked 

During receiving the external input signal

The ON/OFF button cannot be operated in the following situations.

- When "Emergency Stop (Level signal)" is displayed
- When the external input setting is "ON/OFF (Level signal)"



Operation restrictions

If the ON/OFF, Mode, Set Temperature, Air Direction, and Fan Speed buttons on the AT-50B are disabled from other controllers,  will appear on the buttons, and these buttons will not be available for selection. (The buttons may not be disabled depending on the models of the connected indoor unit, controllers, and remote controllers.)


If the AT-50B denies other controllers access to itself (or the "Operation Prohibition Setting" is set to "Enabled"), other controllers cannot disable the functions on the AT-50B.

Menu Screen

The Main Menu screen allows the user to configure the basic settings.

To access the Main Menu screen, touch the  icon at the right top corner of the HOME screen or the menu screens.

Main Menu screen (Top screen)



① HOME button

Accesses the HOME screen.

② Return button

Returns the screen to the previous screen.
(When touched on the Main Menu screen, returns the screen to the HOME screen.)

③ Touch Panel Cleaning button

P64

Touch this button to access the screen that will not respond when touched (except when the numbers in the four corners are touched in a specified order), allowing the user to clean the touch panel without accidentally changing the settings.

④ Service Menu button

Accesses the maintenance menu for service personnel. Normally, general users do not need to change any settings in the maintenance menu.

1 Operation Setting

(1) Time and Schedule	Sets the date, time, schedules, daylight saving changes, and Setback control.	P28
(2) Collective Operation Setting	Sets the collective operation settings.	P40
(3) Group Icon Setting	Changes the behavior of the group icon on the HOME screen. * Three setting options are available.	P43

2 Restriction Settings

(1) Lock Buttons	Locks the buttons and the functions on the AT-50B.	P44
(2) Set Temperature Range Limit	Sets the temperature range for the local remote controllers.	P46
(3) Prohibit Remote Controller	Prohibits access to the ON/OFF, Mode, Set Temperature, Maintenance Sign (Filter sign/Check Water sign) Reset, Air Direction, and Fan Speed settings from the local remote controllers, and also deactivates Timer (Schedule) settings from the local remote controllers.	P48
(4) Operation Mode Selection Limit	Limits the operation mode selection.	P50

3 Control Panel

(1) Display Format	Selects the display formats* on the HOME and menu screens. * Display language, temperature unit, display or non-display of room temperature and cooling/heating mode icons (during Auto mode), and backlight timer, and group names.	P52
(2) Function Key Setting	Assigns the functions to the F1 and F2 buttons. * Setback, Schedule, Mode, Temperature Correction, and RC Prohibition can be assigned.	P56
(3) Volume Control	Sets the sound volume and screen brightness.	P57
(4) Touch Panel Calibration	Calibrates the touch panel.	P58


4 System Management

(1) Status List	Displays errors and maintenance signs.	P59
(2) System-Changeover	Selects the System-Changeover* setting. * Automatically switches the entire system to cooling or heating based on the room temperature and the preset temperature of each group. * This function cannot be used when the Operation Mode Selection Limit function is used.	P61

Usage - Main Menu Settings


Operation Setting

Main Menu > Operation Setting




Main Menu > Operation Setting > Time and Schedule

1 Time and Schedule



Main Menu > Operation Setting > Time and Schedule > Date and Time

A Setting the date, time, and display format



1. Touch the ① **Date and Time** button on the [Time and Schedule] screen.
2. Touch the ② [Date] tab to set the date, or ③ [Time] tab to set the time.
3. Using the ④ ▼ ▲ buttons, set the following items: [Month/Date/Year] and [Hour/Minute/AM · PM].
4. On each tab, select one of the three display formats by checking the ⑤ checkbox next to the desired format.
5. Touch the button ⑥ to access the [Daylight saving changes] screen.
 - Touching the button ⑥ displays a list of countries. Select your country. Select "Not used" if you do not use daylight saving time.
 - If your county does not exist in the list, select "Manual".

The buttons ⑦ become active. Touching the buttons ⑦ displays the date and time setting screen.

Set the start and end date/time.



Daylight saving time setting screen



Date and time setting screen

6. Touch the ⑧ **Save** button.

- The initial date/time setting is 1/1/2013 12:00AM.
- If the clock is set forward, the operations that were scheduled to have taken place before the new time will be cancelled.
- When the daylight saving time goes in effect, the scheduled operations or the Setback operations scheduled for the skipped hour cannot be executed.
- When "Clock setting signal" is set to OFF on the [Initial Settings 1/Basic System] screen under the Service Menu, the daylight saving time function is not available.

[Note] Set the "Clock setting signal" setting to "OFF" if the AT-50B is used as a sub controller, or other controllers periodically issuing a time alarm exist on the same M-NET. If two or more controllers issuing a time alarm exist on the same M-NET, other devices existing on the M-NET fail to synchronize their clock with that of the main controller (master clock), causing malfunctions of the clock-related functions such as the schedule and apportioned electricity billing functions. For details, refer to 2-3. Initial Settings of the Installation Manual.

Usage - Main Menu Settings

Operation Setting (cont'd)

Main Menu > Operation Setting > Time and Schedule > Set Schedules


Ⓑ Setting the operation schedule

Types of schedules		Number of operation patterns
Weekly	Use to assign an operation pattern for each day of the week to be executed every week.	Maximum 12 patterns
One day	Use to assign unique operation patterns for specific dates (up to seven days in advance, including the current date).	Maximum 5 patterns


[Note] If a specific pattern is assigned to multiple groups or days and the configuration of the pattern is changed, the change will be reflected on all the groups and days.

Use a different pattern number to save a given configuration of events if you do not want the changes to be reflected on the groups and days to which the pattern is assigned.

Schedule setting flowchart




Set Schedules screens



Group-and-day/date-selection screen



Seasonal settings screen



Pattern-selection screen





Edit-Pattern screen

Schedule Setting Procedures

1. Touch the “Set Schedules” button on the [Time and Schedule] screen to access the Group-and-day/date-selection screen.

When the selected groups include two or more unit types (e.g. “air conditioners and ventilators” or “general equipment and Air To Water (PWFY)”), the [Target group selection] screen shown on the right appears before the [Set Schedules] screen appears. Select the unit type to be operated, and touch the OK button. (This screen does not appear when the selected groups do not include multiple unit types.)



On the [One day] tab, a 7-day schedule including today will be displayed.

- [Weekly] screen
Displays the pattern numbers that are assigned to groups and days. () will appear on the top left corner of the cell to which one-day schedule is assigned. One-day pattern will override the weekly pattern. The “Seasonal settings” button will appear. On the button, the effective period that was selected on the [Weekly] tab will appear. The effective period can be changed on the [Seasonal settings] screen that will appear when the button is pressed.
- [One day] screen
Displays the one-day schedule patterns that are assigned to specific dates.

2. Touch the [Weekly] or [One day] tab.

When the [Weekly] tab was selected, the seasonal settings must be made as follows.

- (1) Touch the “Seasonal settings” button on the Group-and-day/date-selection screen. (The “Seasonal settings” button appears only on the [Weekly] screen.)
- (2) Touch the button , and select the use or non-use of Weekly2.




: Use Weekly2



: Do not use Weekly2

- (3) Use the   buttons to select the use or non-use of Weekly1 and the effective period for Weekly2. If Weekly2 is set to “Do not use Weekly2,” the effective period cannot be set.
- (4) Pressing the  OK button will take the screen back to the Group-and-day/date-selection screen, and the effective period on the “Seasonal settings” button will be updated. If the effective periods for Weekly1 and Weekly2 overlap, the setting cannot be completed.




Usage - Main Menu Settings

Operation Setting (cont'd)

3. Select the cell where a specific group and a day (date) intersect to assign a pattern.
- * Patterns can be copied, pasted, or deleted on the Group-and-day/date-selection screen.
(e.g., The weekly schedule of a specific group can be copied and pasted to another group, or the schedule pattern of a specific day can be copied and pasted to another day. Refer to P34 for details.)
4. On the Pattern-selection screen, select [--] (deselected) or one of the 12 or 5 patterns (between [P01] and [P12] on the [Weekly] tab OR between [P01] and [P05] on the [One day] tab). Each pattern can be newly configured, copied and pasted, or edited. See ①, ②, and ③ below for details.

Touch a schedule pattern to select it.

Black pattern numbers indicate that the patterns have already been configured, and the white ones indicate blank patterns.



Operation pattern numbers

Scheduled events for the selected pattern

- Appears only if the selected pattern has been configured.
- The functions not supported by the selected group will appear underlined in red, and they will not be executed.

* Touch the < > buttons to check the actions for each scheduled event.

* Refer to P36 for icon definitions.

① To configure a new pattern using a blank pattern

Touch a blank pattern number, then touch the  button to access the Edit-Pattern screen.
⇒ See Step 5.

If one or more patterns have been configured and saved, the message “When copying other setting patterns to edit, select the pattern to be copied, and touch the OK button.” will appear. Touch the OK button to create a new pattern using a blank pattern. To use an existing pattern as a template, select a desired pattern and then touch the OK button.

- ② To copy an existing pattern and paste it to selected days or dates

Touch a pattern number to select it, then touch the OK button to return to the Group-and-day/date-selection screen. To set the schedule for other groups or days/date ⇒ See Step 2.


When setting is complete ⇒ See Step 10.

- ③ To edit an existing pattern

Touch an existing pattern number, then touch the  button to access the Edit-Pattern screen.
⇒ See Step 5.

If the selected pattern number is assigned to other groups or days, the message “This pattern is used for another schedule. To use different pattern number, select the number, and touch the OK button.” will appear. To change the schedule of the day or date that was selected in Step 3 above alone, select a new blank pattern number and then touch the OK button. To change the setting of all groups and days to which the pattern is assigned, just touch the OK button.

5. On the Edit-Pattern screen, touch an event number to edit its contents.



ON/OFF, Mode, Set Temperature, and Fan Speed

Air direction, Prohibit Remote Controller Operation

*1 The scheduled actions for each event will be displayed over two pages.

Use the scroll buttons to switch between the pages.

*2 On the Edit-Pattern screen, the events of a specific pattern can be copied and pasted to another pattern.

Refer to P34 for details

Usage - Main Menu Settings

Operation Setting (cont'd)

6. Set the time and the actions for the selected event number.



Auto (dual set point) mode



* Functions that can be included in each event are as follows: Execution Time, ON/OFF, Mode, Fan Speed¹, Air Direction¹, Set Temperature, and Prohibit Remote Controller Operation settings.

* Refer to P36 for icon definitions.

* The set temperature must be set to a temperature within the range that was specified in the Initial Settings 1/Basic System under the Service Menu².

Refer to the Installation Manual to change the temperature setting range.

*1 For air conditioning unit groups and LOSSNAY groups

*2 For air conditioning unit groups

7. When finished making the settings, touch the OK button to return to the Edit-Pattern screen.

8. Repeat Steps 5 through 7 above to set as many events and the execution time for the events as necessary.

9. When finished, touch the Return button  to return to the Group-and-day/date-selection screen. To set the schedule for other groups or days/date ⇒ See Step 2.

When setting is complete ⇒ See Step 10.

10. To exit the screen and return to the [Time and Schedule] screen, press  on the Group-and-day/date-selection screen.

Copying, pasting, deleting, and inserting settings

Check the checkbox next to the  button to activate the  **Copy**,  **Paste**,

 **Delete**, and  **Insert** buttons.

.....

Copying and pasting the existing settings

- 1. Touch the item to be copied.
 - * Items that can be copied include the weekly schedule for a group, the pattern assigned to a specific day, or the event that is scheduled to take place at a certain time.
 - * A red checkmark will appear on the selected item(s).

(Example) To copy the weekly schedule for a group



(Example) To copy an event (a set of actions executed at a scheduled time)



- 2. Touch the  Copy button. The selected item will be highlighted in blue.



- 3. Touch the copy destination.
 - * Multiple copy destinations can be selected.
 - * A red checkmark will appear on the selected item(s).

- 4. Touch the  **Paste** button.
- 5. Touch the **OK** button on the window that pops up.

.....

Deleting selected settings

- 1. Touch the items to be deleted.
 - * Items that can be deleted at once include the weekly schedule for a group, the pattern assigned to a specific day, or the event that is scheduled to take place at a certain time.
 - * Multiple items can be deleted at once.
- 2. Touch the  **Delete** button.
- 3. Touch the **OK** button on the window that pops up.

Usage - Main Menu Settings

Operation Setting (cont'd)

Inserting an event

- 1. Touch a row to insert an event above it.
 - * A red checkmark will appear on the selected row.
- 2. Touch the  **Insert** button. A blank row will appear above the selected row.
 - * If the maximum number of events have been set, no more rows can be inserted.

Icon Definitions

(Air conditioning unit groups and LOSSNAY groups)

Functions	Deselected ^{*1}	Setting Options
ON/OFF		On [green] Off [black]
Mode		Cool Dry Fan Heat Auto (Single/dual set point(s)) Bypass Heat recovery Auto Damper
Fan Speed		Quiet Low Mid High Auto
Air Direction		Setting 1 Setting 2 Setting 3 Setting 4 Setting 5 Swing Auto
Local remote controller operation prohibition (ON/OFF)		Permit Prohibit
Local remote controller operation prohibition (Mode)		Permit Prohibit
Local remote controller operation prohibition (Set Temperature)		Permit Prohibit
Local remote controller operation prohibition (Filter Sign Reset)		Permit Prohibit

(General equipment groups and Air To Water (PWFY) groups)


Functions	Deselected ^{*1}	Setting Options
ON/OFF		On [green] Off [black]
Mode		Heating Heating ECO Hot Water Anti-freeze Cooling
Local remote controller operation prohibition (ON/OFF)		Permit Prohibit
Local remote controller operation prohibition (Mode)		Permit Prohibit
Local remote controller operation prohibition (Set Temperature)		Permit Prohibit
Local remote controller operation prohibition (Check Water Sign Reset)		Permit Prohibit

^{*1} The icons corresponding to the functions that are not scheduled will not be displayed except in the Edit-Pattern popup screen.


© Setting the Night Setback function

Night Setback function (hereafter abbreviated as Setback) is a function that prevents indoor dew or extreme temperature rise by heating/cooling automatically when the room temperature goes outside of the specific range during the set time period.

- In a group where both Air To Water (PWFY) and air conditioning units are connected to Y series outdoor unit, Setback function may not function properly.
 - When the air conditioning group with Setback function is off and when the temperature exceeds the preset temperature, heating/cooling operation starts.
 - If the room temperature is measured by the air-conditioner's suction temperature sensor, the temperature may not be correct when the air-conditioner is inactive and the air is not fresh. When the air-conditioner is inactive, using a remote sensor or a remote control sensor is recommended to measure room temperature correctly.
 - If the temperature setting, ON/OFF operation, or Timer (Schedule) execution is prohibited for this unit, Setback operation cannot be used.
 - If the operation mode change is prohibited or the operation mode selection is limited for this unit, Setback function may not function properly.
- When the Setback control is set, air conditioning group operates as shown below.



When the temperature drops below the lower limit temperature (heating control)



When the temperature rises above the upper limit temperature (cooling control)

If "Unscheduled" is selected, the Setback function that were set on the [Setback Control] screen will not be executed with the pressing of the Collective Operation button. In this case, the settings that were made on the [Collective Operation] - [Setback] screen will override the settings made on the [Setback Control] screen, and the scheduled operation will not run.

1. Touch the © **Setback Control** button on the [Time and Schedule] screen.
2. Read the pop-up message, and touch the **OK** button to confirm.



Usage - Main Menu Settings

Operation Setting (cont'd)

3. Press button ① to bring up the screen to set the control time period and the lower/upper limit temperatures.

Setting of Setback control time period

Touch the ② ▼▲ buttons to set the control time.



Setting of lower/upper limit temperature

Touch the ③ ▼▲ buttons to set the upper and lower limits.

When [--] is set, Setback control will not be operated.

Touch OK to close the popup window and return to the [Setback Control] screen. The new settings will appear on the display section ④ on the screen.

Pressing the Cancel button will close the popup window, but the new setting will not be reflected on the display section ④ on the screen.

4. Press the button labeled ⑤ to set different lower/upper limit temperature for different groups.


The groups whose temperature setting is different from the one for the collective setting will appear underlined .

5. Select the groups to include from the group buttons labeled ⑥. By default, all groups are selected.
6. Touch the ⑦ **Save** button.

- The minimum difference between the upper and lower limits is 4°C (8°F).
- The temperature range that can be set depends on the connected units.
- The temperature can be set within the following range.
[Upper limit] 19°C - 30°C [19°C - 30°C] / 67°F - 87°F [67°F - 87°F]
[Lower limit] 12°C - 28°C [17°C - 28°C] / 53°F - 83°F [63°F - 83°F]
* [] in case of using Mr.SLIM® units.
- The groups that do not support the Setback function cannot be selected.
- The changes that are made while the Setback function is turned on will not be reflected. To have the settings reflected, turn off the Setback function and then turn it back on. Refer to P20 for how to turn on/off the Setback function.
- The Setback status can be verified by accessing the [Check Current Settings] screen from the [Time and Schedule] screen.

D Checking the weekly/one-day schedule settings

When the selected groups include two or more unit types (e.g. “air conditioners and ventilators” or “general equipment and Air To Water (PWFY)”), the [Target group selection] screen shown on the right appears before the [Check Current Settings] screen appears. Select the unit type to be operated, and touch the OK button. (This screen does not appear when the selected groups do not include multiple unit types.)



1. Touch the “Check Current Settings” button on the [Time and Schedule] screen.

[Weekly] tab

[One day] tab

Day (Date) grid

Displays scheduled patterns

- [Weekly] screen
 - Displays the pattern numbers that are assigned to groups and days. (**1**) will appear on the top left corner of the cell to which one-day schedule is assigned.
 - One-day pattern will override the weekly pattern.
- [One day] screen
 - Displays the one-day schedule patterns that are assigned to specific dates.

Seasonal settings (Weekly only)

2. Touch the [Weekly] or [One day] tab.

3. Touch the row that corresponds to the group whose schedules you want to check.

Touch the pattern number under a specific day to check the day's schedule that appears under the pattern numbers.

Effective time for the Setback function

Operation pattern numbers

Scheduled events for the selected pattern

- Appears only if the selected pattern has been configured.
- The functions not supported by the selected group will appear underlined in red, and they will not be executed.
 - * Refer to P36 for icon definitions.
- The effective time for the Setback function will appear as a yellow line on the timeline.

4. Touch the < > buttons to check the actions for each scheduled event.


Touch the “Close” button to return to the previous screen.

5. To change the schedule settings, touch the Return  button to return to the [Time and Schedule] screen, and access the [Set Schedules] screen.

Usage - Main Menu Settings

Operation Setting (cont'd)

Main Menu > Operation Setting



Main Menu > Operation Setting > Collective Operation Setting

2 Setting the collective operation settings



• When **X** appears on the “RC Prohibition” button, this function will not be available.

To select the groups on which to execute the collective ON/OFF function

1. Touch the ① **ON/OFF** button on the [Collective Operation Setting] screen.
2. Read the pop-up message, and touch the **OK** button to confirm.
3. Select the groups to include from the group buttons labeled ①. By default, all groups are selected.
4. Touch the ② **Save** button.

Show Group Name List button

Shows a list of group names in a pop-up window.



Select All button
Selects all groups.

• The DIDO controller groups that do not support the collective ON/OFF function cannot be selected.

To select the groups on which to execute the collective operation
(Enable or disable the Setback function)


- 1. Touch the ② **Setback** button on the [Collective Operation Setting] screen.
- 2. Read the pop-up message, and touch the **OK** button to confirm.
- 3. Touch the ③ **▼▲** buttons to set the upper and lower limits. Press the button labeled ④ to set different ranges for different groups. The groups whose temperature setting is different from the one for the collective setting will appear underlined G10.
- 4. Select the groups to include from the group buttons labeled ⑤. By default, all groups are selected.
- 5. Touch the ⑥ **Save** button.



- The minimum difference between the upper and lower limits is 4°C (8°F).
- The temperature range that can be set depends on the connected units.
- The groups that do not support the Setback function cannot be selected.
- The changes that are made while the Setback function is turned on will not be reflected. To have the settings reflected, turn off the Setback function and then turn it back on. Refer to P20 for how to turn on/off the Setback function.

To select the groups on which to execute the collective operation
(Enable or disable scheduled operation)

- 1. Touch the ③ **Schedule** button on the [Collective Operation Setting] screen.
- 2. Read the pop-up message, and touch the **OK** button to confirm.
- 3. Select the groups to include from the group buttons labeled ⑤. By default, all groups are selected.
- 4. Touch the ⑥ **Save** button.



Usage - Main Menu Settings


Operation Setting (cont'd)

To select the groups on which to execute the collective operation (Mode)

1. Touch the ④ **Mode** button on the [Collective Operation Setting] screen.
2. Read the pop-up message, and touch the **OK** button to confirm.
3. Select the groups to include from the group buttons labeled (A). By default, all groups are selected.
4. Touch the (B) **Save** button.

Show Group Name List button

Shows a list of group names in a pop-up window.




- The DIDO controller groups, the LOSSNAY groups, and the Air To Water (PWFY) groups that do not support this function cannot be selected.

To select the groups on which to execute the collective operation (Temperature Correction)

1. Touch the ⑤ **Temperature Correction** button on the [Collective Operation Setting] screen.
2. Read the pop-up message, and touch the **OK** button to confirm.
3. Select a value to be used as the temperature offset value from the buttons labeled (C).
4. Select the groups to include from the group buttons labeled (A). By default, all groups are selected.
5. Touch the (B) **Save** button.

Show Group Name List button

Shows a list of group names in a pop-up window.



- The Temperature Correction function is used to temporarily raise or lower the preset temperature setting by a certain preselected amount.
- Positive offset is used for units that are operated in the cooling and dry modes, and negative offset is used for units that are operated in the heating mode.
- The DIDO controller groups, the LOSSNAY groups, and the Air To Water (PWFY) groups that do not support this function cannot be selected.
- When the operation mode or the temperature setting is changed in the group that is executing the temperature correction function, the temperature correction will be cancelled.

To select the groups on which to execute the collective operation (Locking or unlocking access to the setting items in the table below from the local and other system controllers)

- 1. Touch the ⑥ **RC Prohibition** button on the [Collective Operation Setting] screen.
- 2. Read the pop-up message, and touch the **OK** button to confirm.
- 3. Select the groups to include from the group buttons labeled (A). By default, all groups are selected.
- 4. Touch the (B) **Save** button.

•The settings that can be locked or unlocked depend on the type of group.

	Indoor unit groups	LOSSNAY groups	Air To Water (PWFY)
① ON/OFF	☐	☐	☐
② Mode	☐	☒	☐
③ Set Temperature	☐	☒	☐
④ Maintenance Sign (Filter sign/Check Water sign) reset	☐	☐	☐
⑤ Air Direction	☐ *1	☒	☒
⑥ Fan Speed	☐ *1	☒	☒
⑦ Timer	☐ *1	☒	☒


*1: [Air Direction], [Fan Speed], and [Timer] may not be locked, depending on the connected remote controller or unit model.

Show Group Name List button
Shows a list of group names in a pop-up window.



Select All button
Selects all groups.

Main Menu > Operation Setting



Main Menu > Operation Setting > Group Icon Setting

③ To make group icon settings

Touch the ③ **Group Icon Setting** button on the [Operation Setting] screen.



Group icon setting 1
Stops or starts the operation of the specific group of units when the group icon is touched.

Group icon setting 2 (default)
Allows the user to select multiple groups before jumping to the GROUP screen. Touch the **Operate** button after selecting groups to jump to the GROUP screen.


Group icon setting 3
Jumps to the GROUP screen when a group icon is touched.

- 1. Select among Group icon setting 1, Group icon setting 2, and Group icon setting 3 by touching the corresponding button labeled ① .
- 2. Touch the ② **Save** button.

Usage - Main Menu Settings

Restriction Settings


Main Menu > Restriction Settings



Main Menu > Restriction Settings > Lock Buttons

1 Selecting the functions to be locked and setting the password to unlock the locked functions

Selecting the functions to be locked



1. Touch the ① **Lock Buttons** button on the [Restriction Settings] screen.
2. Enter the password on the [Login Page] screen, and touch the **Login** button. Refer to below for the details on log in. If the correct password is entered, the [Lock Buttons] screen will appear.
3. Press the **Category** button ① that includes the function to be locked. The screen that looks like the figure above will appear. (The items in each category and the type of functions that can be locked are summarized in Table A.)
4. Touch the button ② that corresponds to the function to be locked so that  will appear. (The items whose corresponding icon is  cannot be locked.)
5. Touch the ③ **Save** button.

Table A. List of items and functions that will be locked in each category

Category button	Item	Function that will be locked	Category button	Item	Function that will be locked
	ON/OFF	Collective ON/OFF button *1		ON/OFF	ON/OFF button *3 *4
	F1	Function 1 button *1		Mode	Mode button *3 *4
	F2	Function 2 button *1		Set Temp.	Set temperature button *3 *4
	Screen	Touch panel screen *2		Fan Speed	Fan speed button *3 *4
	Main Menu	Main Menu button		Schedule ON/OFF	Schedule ON/OFF button *3 *4

*1 If the function is locked, the LED on the button will blink twice when touched.
*2 When the touch panel screen is locked, the category  or  will not be available for selection.
*3 The buttons that can be locked are the ones that appear on the HOME screen.
*4 On the HOME screen, the  icon will appear on the buttons that are locked.


Setting the unlock password



1. Touch the ① **Lock Buttons** button on the [Restriction Settings] screen.
2. Enter the password on the [Login Page] screen, and touch the **Login** button. Refer to below for the details on log in. If the correct password is entered, the [Lock Buttons] screen will appear.
3. Press ① . The screen that looks like the figure at left will appear.
4. To allow unlocking the buttons without entering the password, touch ② **No password** to activate the button. To require a password to unlock the buttons, touch ② **Password** to activate the button.
5. Touch the ③ **Save** button.

Use the same password as the login password to unlock buttons.


To log in



1. Enter the login password from the ① keyboard on the touch panel. Touch ② to delete a character.
2. Touch the ③ **Login** button.
If the password matches, the Lock Buttons screen will be displayed.

- The initial login password is "0000". Change the password if necessary.
- If you forget the password, refer to the Installation Manual.

To change the password




1. Enter the current password on the login screen, and then touch ④ . The screen at left will appear.
2. Enter the new password in the ⑤ [New Password] field.
* Password should be between four and eight characters.
Touch ⑧ to delete a character.
3. Touch the ⑥ [Retype Password] field, and enter the new password again.
4. Touch the ⑦ **OK** button to reflect the change and return to the previous screen.

Usage - Main Menu Settings

Restriction Settings (cont'd)

Main Menu > Restriction Settings



Main Menu > Restriction Settings > Set Temperature Range Limit

2 Setting the temperature ranges within which the operating temperatures can be set from the local remote controllers

① **Show Group Name List** button

Displays a list of group names in a pop-up window.

② **Group** buttons

Displays group numbers. Touch the button for a specific group to edit the settings.

Select All button

Selects all groups.

	Cool	Heat	Auto
601	24-28°C	--- °C	--- °C
602	26-28°C	20-23°C	--- °C
603	26-28°C	20-23°C	--- °C
604	26-28°C	20-23°C	19-23°C

③ **Edit** button

Edits the temperature range for the selected group.

▼ ▲ buttons


Use to flip through the pages. (Each page lists four groups.)

1. Touch the 2 **Set Temperature Range Limit** button on the [Restriction Settings] screen.
2. Read the pop-up message, and touch the **OK** button to confirm.
3. Touch the ② **Group** button to select the groups to change their settings.
4. Touch the ③ **Edit** button.

5. Use the ④ ▼ ▲ buttons shown in the pop-up window at right to set the range for each operation mode (Cool, Heat, and Auto).

To clear the lower limit, keep hitting the ▼ button until -- appears. To clear the upper limit, keep hitting the ▲ button until -- appears.

Not all functions are supported by all local remote controllers. The ▼ ▲ buttons for the unsupported functions will be grayed out.




6. Touch the ⑤ **OK** button to save the settings.

- The temperature setting range and the operation mode that can be set depend on the indoor unit and remote controller models.
- The cooling and heating temperature ranges can be set under the following conditions.
 - The difference between the cooling and heating upper limit temperatures is equal or greater than the minimum temperature difference that varies with the indoor unit model.
 - The difference between the cooling and heating lower limit temperatures is equal or greater than the minimum temperature difference that varies with the indoor unit model.
- Operation from the local remote controllers that are connected to Mr. SLIM® cannot be prohibited from the AT-50B. Use the button lock function on the controllers instead.
- If the temperature limits are set too high or low, the System-Changeover function may not work properly and the units may not operate in the expected mode (Cool or Heat).
- When using the System-Changeover function, it is recommended not to use the temperature range limit function.
- The DIDO controller groups, the LOSSNAY groups, and the Air To Water (PWFY) groups do not support the Set Temperature Range Limit function.
- If two or more system controllers exist in the same system, select only one controller to set the Set Temperature Range Limit. Setting the Set Temperature Range Limit from the other system controllers causes duplicate settings and prevents the system from operating as intended.

Usage - Main Menu Settings

Restriction Settings (cont'd)

Main Menu > Restriction Settings




In the following situation, will appear on the Prohibit Remote Controller button, and this function is not available for selection:

- The "Operation Prohibition Setting" is set to "Disabled."

Main Menu > Restriction Settings> Prohibit Remote Controller

3 Locking or unlocking access to the setting items in the table below from the local and other system controllers



- When accessing the settings that are locked,  will appear over the corresponding icons.
- The settings that can be locked or unlocked depend on the type of group.


	Indoor unit groups	LOSSNAY groups	Air To Water (PWFY)
① ON/OFF	○	○	○
② Mode	○	×	○
③ Set Temperature	○	×	○
④ Maintenance Sign (Filter sign/Check Water sign) reset	○	○	○
⑤ Air Direction	○ *1	×	×
⑥ Fan Speed	○ *1	×	×
⑦ Timer	○ *1	×	×

*1 [Air Direction], [Fan Speed], and [Timer] may not be displayed, depending on the connected remote controller or unit model.

1. Touch the **③ Prohibit Remote Controller** button on the [Restriction Settings].
2. Read the pop-up message, and touch the **OK** button to confirm.
3. Touch the **② Group** button to select the groups and change their settings.
4. Touch the **③ Edit** button.
5. When the groups selected in step 3 include two or more unit types (Air conditioners, LOSSNAY, or Air To Water (PWFY)), the unit type selection screen appears. Select the unit type to be operated.
(The unit type marked **×** cannot be selected.)
6. Use the buttons labeled **④** in the pop-up window at right to lock or unlock access to each item.
7. Touch the **⑤ OK** button to save the settings.



The display will change as follows every time the button is touched.




- The screen will always display the latest prohibit/permit status. If an event takes place that changes the prohibit/permit status of a specific item, the screen display will be updated. (The mark will appear or disappear.)
- When this function is in use (or the "Operation Prohibition Setting" is set to "Enabled"), the buttons on AT-50B cannot be disabled from the system controller.

Usage - Main Menu Settings

Restriction Settings (cont'd)

Main Menu > Restriction Settings



In the following situations, **X** will appear on the Operation Mode Selection Limit button, and this function is not available for selection:

- The AT-50B is set as a sub controller.
- The System-Changeover function is available.

Main Menu > Restriction Settings> Operation Mode Selection Limit

4 Operation Mode Selection Limit (season changing)

Selection to specific operation modes with this controller or the local remote controller for all groups can be limited.

For example, the mode selection can be limited according to the season.

Cooling mode limit (winter), heating mode limit (summer), cooling + heating mode limit (between seasons)



1. Touch the **4 Operation Mode Selection Limit** button on the [Restriction Settings] screen.

2. Touch the **1** button to set the operation mode limit.

* Touch the **1** button repeatedly to select from following settings.



①Button	Explanation
No Limitation	The limits will be cancelled.
No Cooling Operation	Cool, Dry, and Auto modes cannot be selected with the Mode button.
No Heating Operation	Heat and Auto modes cannot be selected with the Mode button.
No Heating/Cooling	Cool, Dry, Heat, and Auto modes cannot be selected with the Mode button.

Press the button labeled ② to set different limitation type for different groups.

The groups whose limitation setting is different from the one for the collective setting will appear underlined  .

3. Select the groups to include from the group buttons labeled ③ .


4. Touch the ④ **Save** button.

- Note that this function cannot be used with some indoor units. In this case, changeover of the operation mode cannot be limited with the local remote controller.
- The DIDO controller groups, the LOSSNAY groups, and the Air To Water (PWFY) groups that do not support this function cannot be selected.
- In a group where both Air To Water (PWFY) and Air conditioning units are connected to Y series outdoor unit, Operation Mode Selection Limit may not function properly.

Usage - Main Menu Settings

Control Panel

Main Menu > Control Panel



Main Menu > Control Panel > Display Format

1 Setting the basic display settings on the HOME and menu screens

Touch the ① **Display Format** button on the [Control Panel] screen.

- The [Display Format] screen consists of three pages (1/3 - 3/3). Use the ④ ▼ ▲ buttons to flip through the pages. After setting all the settings, touch the ⑤ Save button.

[Display Format] screen: 1/3



To select the display language

1. Touch the ① **Language** button on the [Display Format] screen (1/3).
2. Select a desired language from the language options (buttons labeled ⑥ in the figure) on the pop-up screen.
3. Press the ⑦ **OK** button to return to the previous screen.



To select the temperature unit

Touch the ② Temperature unit button on the [Display Format] screen (1/3) to toggle through °F , °C , and 1°C.

- °F: Temperature is displayed in Fahrenheit.
- °C: Temperature is displayed in 0.5°C increments. (Even if "°C" is selected, temperatures will be displayed in 1°C increments for the Air To Water (PWFY) unit groups.)
- 1°C: Temperature is displayed in 1°C increments.

To show or hide the room temperature

Touch the ③ **Room Temperature** button on the [Display Format] screen (1/3) to switch between Show and Hide.


[Display Format] screen 2/3



To show or hide the Cool/Heat mode icon (during Auto mode) when the operation mode is enabled

Touch the ⑧ **Automatic Mode Display Setting** button to switch between Show ( / ) and Hide ().

Example) HOME screen



To set the backlight timeout time

Touch the ⑨ **Backlight Timeout Setting** button to set the timeout time.
The backlight will go off after a specified time of non-use.

* Touch the button repeatedly to select from the following settings.


1 min. → 3 min. → 5 min. → 7 min. → 10 min.

The backlight will remain lit as long as an error exists.

Usage - Main Menu Settings


Control Panel (cont'd)

Main Menu > Control Panel



Main Menu > Control Panel > Display Format

[Display Format] screen : 3/3



To change the group name

1. Touch the ⑩ **Jump to the group name setting screen** button on the [Display Format] screen (3/3).
2. Select a desired group name button labeled ⑪ on the [Group Name Setting] screen to change its group name.
3. Enter the group name on the pop-up window. (Refer to the next page for details.) Group names can be copied and pasted by using the ⑫ **Copy** and ⑬ **Paste** buttons.
4. Touch the ⑤ **Save** button.

.....

Character input screen



To enter character strings such as group names (maximum 16 characters), perform the following procedure.

.....


To enter a character string

1. Touch ① **ABC**, **abc**, **1()**, **AEB**, or **a6B** to select upper case alphabets, lower case alphabets, or numerical and other symbols.
2. Enter characters from the ② keyboard.
 - * Scroll the screen up and down with the ③ **▼** **▲** buttons to see all characters.
 - * To correct a character, move the cursor over the character with the ④ **◀** **▶** button, and then either delete it with the ⑤ **Delete** button or overwrite it with a new character.
3. When complete, touch the ⑥ **OK** button to return to the previous screen.

Usage - Main Menu Settings

Control Panel (cont'd)


Main Menu > Control Panel



Main Menu > Control Panel > Function Key Setting

2 Assigning Collective Operation functions to the Function 1 button (F1) and Function 2 button (F2)

Touch the 2 **Function Key Setting** button on the [Control Panel] screen.




1. Touch the check mark ☒ that corresponds to the function to assign to F1 or F2 so that the checkmark will appear as ☒.

(Check the check mark in the F1 column to assign a function to F1, and check the check mark in the F2 column to assign a function to F2. Touch the button again so that the button will appear as ☒ to cancel the selection.)

2. Touch the 3 **Save** button.

- As a default, no functions are assigned to either F1 or F2.
- The F1 and the F2 will be effective only on the HOME screen.
- To use the F1 or F2 button to execute a function, certain settings for Collective Operation must be set. (Refer to P40 for information about the Collective Operation settings.)
- If "X" appears on the checkbox, the function that corresponds to the checkbox is not available and the function cannot be assigned to the F1 or F2 button.


Main Menu > Control Panel



Main Menu > Control Panel > Volume Control

3 Adjusting the volume and brightness

Touch the 3 **Volume Control** button on the [Control Panel] screen.



To adjust the volume

1. Touch the ① **Sound** button on the [Volume Control] screen.

Every time the ① **Sound** button is touched, the sound level changes as follows: [Level 0] → [Level 1] → [Level 2] → [Level 3].

2. Touch the ③ **Save** button.

To adjust the brightness

1. Touch the ② **Brightness** button on the [Volume Control] screen.

Every time the ② **Brightness** button is touched, the brightness level changes as follows: [70%] → [80%] → [90%] → [100%].

2. Touch the ③ **Save** button.


- The volume and brightness settings will be changed immediately, but will not be saved until the ③ **Save** button is touched.

Usage - Main Menu Settings

Control Panel (cont'd)

Main Menu > Control Panel > Touch Panel Calibration

④ Calibrating the touch panel




1. Touch the ④ **Touch Panel Calibration** button on the [Control Panel] screen.
Touch the **OK** button on the confirmation screen.
2. Touch the white squares (④) in the order they appear, starting from the top left corner.
3. After all nine squares are touched, the screen will return to the [Control Panel] screen.

- If each square is not touched within one minute after the last square is touched, calibration will be cancelled and the screen will return to the [Control Panel] screen.
 - To calibrate the screen properly, use a pointy, but not sharp object to touch the squares.
- * Sharp objects may scratch the touch panel.

System Management

Main Menu > System Management



Main Menu > System Management > Status List

1 Checking or resetting the Error or the Maintenance Sign

Touch the 1 **Status List** button on the [System Management] screen.

Number of errors

Displays the number of errors.

Group names

Displays the name of the group that includes the unit whose Error/Filter signs are turned on.

1

No.	Group Name	Address	Error Code
1	LIVING ROOM	001	6607
2	DINING ROOM	002	6607
3	ENTRANCE	003	6607

2

Error source address

Displays the M-NET address of the units whose Error/Filter signs are turned on.

Error code

Displays the code for the error that were detected.

To check the error

1. Touch the 1 [Malfunction] tab to check the number of errors, the names of the group in which the errors occurred, the addresses of the error-source units, and the error codes.


• If an error occurs, note the error code and consult your dealer or a maintenance provider.

To reset the error

1. Touch the 1 [Malfunction] tab.
2. Touch the 2 **All Reset** button.
3. Touch the **OK** button on the pop-up window.

• Those groups whose errors have been reset will have an icon indicating that they are stopped.

System Management (cont'd)



To check the information about the units whose maintenance signs are turned on

1. Touch the ③ [Maintenance Sign] tab, and check the number of units whose maintenance signs are turned on, the names of the groups they belong to, and their addresses.


- When a filter sign appears, clean, wash, or replace the filter as necessary. Refer to air conditioner or LOSSNAY manual for details.
- When  appears on the **Reset** button, the button will not be available.

To reset the maintenance sign (for example, after cleaning the filter)

- ④ **Reset** button : Clears the specific maintenance sign.
- ⑤ **All Reset** button : Clears all filter signs.

(This button is not available for the Air To Water (PWFY) groups.)

Main Menu > System Management



In the following situations, **X** will appear on the System-Changeover button, and this function is not available for selection:

- The AT-50B is set as a sub controller.
- The changeover limit function of the operation mode is available.

Main Menu > System Management > System-Changeover

2 Using the System-Changeover function

Use the System-Changeover mode to automatically change a group of indoor units that are connected to the same outdoor unit over between the cooling and heating modes according to temperature changes.

Use this function to control the indoor units that do not have an automatic changeover mode. They can be operated in the heating mode in the morning, and then automatically changed over to the cooling or heating mode all at once in the afternoon, for example, without the need to manually change the mode via each remote controller.

- * This function should not be used in conjunction with the System-Changeover function on the outdoor unit or other system controllers.
- * When the System-Changeover mode is set to [Averaging], the operation mode is selected based on the demands of the majority of the group, taking into consideration the capacity of each indoor unit. When it is set to [Representative Group], the operation mode is selected based on the demand of the representative group through updating its status every 15 minutes and changing over to the cooling or heating mode as necessary. Because the operation mode is selected based on the demands of the representative group or of the majority of the groups, not all areas may be air conditioned to the optimum temperature.

- If the temperature limits are set too high or low (see P46), the System-Changeover function may not work properly and the units may not operate in the expected mode (cooling or heating).
- The System-Changeover function is not available for the following types of products:
- Simultaneous Cooling/Heating units (with Auto mode), Mr. SLIM®, LOSSNAY, DIDO controller, and Air To Water (PWFY).

Usage - Main Menu Settings

System Management (cont'd)

Operation mode

Displays the current operation mode.

Cool:  Cool

Heat:  Heat

Block No.

Displays the block number. All units in each group are operated in the same operation mode. The AT-50B automatically creates blocks based on the refrigerant pipe connection information and the group setting information on each unit.




Group list

Displays the number assigned to the indoor unit groups that are connected to the outdoor units in a specific block. Select a representative group from this list when the [Representative Group] is selected for the System-Changeover mode.

Display Block Information button

Displays the addresses of the outdoor units and the names of the groups in a specific block.



1. Touch the **2** **System-Changeover** button on the [System Management] screen.
2. Touch the **1** **Change mode** button to select between [None], [Averaging], and [Representative Group].

System-Changeover mode	Setting
None (default)	Select this option so as not to use the System-Changeover function.
Averaging	The operation modes (Cool/Heat) will be changed-over based on the following: Temperature differences between the preset temperature and the room temperature of all indoor unit groups that are connected to a specific outdoor unit, AND the capacity of each indoor unit in each group. * The operation mode of the groups of units that are not operating, or the ones that are operating in the Fan or Auto mode, will remain the same.
Representative Group	The operation modes (Cool/Heat) will be changed-over based on the temperature difference between the preset temperature of the representative group and the room temperature. * When the air conditioning units in the representative group are not operating, or they are operating in the Fan or Auto mode, the System-Changeover function will work in the same way as when the System-Changeover mode is set to Averaging.

When [Representative Group] is selected, the group that is currently designated as the representative group will be displayed.

- * To designate a different group as the representative group, select a new group on the screen that appears (shown right) when the **2** **Representative Group** button is pressed, and then touch the **OK** button.




- The initial setting for the representative group is the group in a specific block with the smallest group number.
- In a group where both Air To Water (PWFY) and Air conditioning units are connected to Y series outdoor unit, System-Changeover function may not function properly.


3. Touch the **3** **Save** button on the [System-Changeover] screen.

The System-Changeover function operates depending on whether the group supports the Auto (dual set point) mode or not.

1) Groups not supporting the Auto (dual set point) mode




2) Groups supporting the Auto (dual set point) mode



- Do not set the heating temperature above the cooling temperature.
 - In the case of groups that support the Auto (dual set point) mode, a huge difference between the heating and cooling temperatures may delay the changeover of the operation mode. It is recommended to set heating and cooling temperatures to the same value.

Maintenance

Touch Panel Cleaning screen



To clean the touch panel

This screen allows the user to wipe the touch screen without accidentally changing the settings.

1. Touch the  icon on the Main Menu screen to bring up the screen shown above.
2. When done cleaning the touch panel, touch the four numbers in the corners 1, 2, 3, and 4 in that order to return to the Main Menu screen.

- The four numbers must be touched in the correct order. If you touch the numbers in the wrong order, start over from 1.
- Wipe with a soft dry cloth, a cloth soaked in water with mild detergent, or a cloth dampened with ethanol. Do not use acidic, alkaline, or organic solvents.

Troubleshooting

Problem

The indicator on the Collective ON/OFF button is blinking.

Solution

Touch Main Menu > System Management > Status List.
On the Malfunction tab, check the error code and the error source address on the screen, and consult your dealer.
Refer to P59.

Problem

⚠️ ? is displayed on the screen.




Solution

Touch Main Menu > System Management > Status List.
On the Malfunction tab, check the error code and the error source address on the screen, and consult your dealer.
Refer to P59.

Problem

A filter sign is displayed on the screen.



Solution

Touch Main Menu > System Management > Status List.
On the Maintenance Sign tab, check the address on the screen.
Clean the filter on the unit whose filter sign is on according to the instructions in the manual for the applicable unit.
Refer to P59.

Problem

[Emergency Stop (Level signal)] is displayed on the screen, and the controller does not respond to the **ON/OFF** button.



If the external input interface receives an emergency stop signal, all indoor units, LOSSNAY, and Air To Water (PWFY) units that are controlled by the AT-50B will stop.
The AT-50B controller, low-level system controllers, or local remote controllers will not respond until the emergency stop signal input is removed. When the emergency stop signal is removed, the operation status before the signal was received will be restored.

Specifications			
Power source		30VDC *1 (for connection to M-NET only)	Receives power from the power supply unit for transmission cable or from outdoor units via the M-NET transmission cable. The power consumption coefficient*2 of AT-50B is "4."
Operating conditions	Temperature	Operating temperature range	0 - 40°C [32°F - 104°F]
		Storage temperature range	-20 - +70°C [-4°F - +158°F]
	Humidity	30%~90%RH (Non-condensing)	
Weight		0.5 kg [1-1/8 lbs]	
External dimensions (W x H x D)		180 x 120 x 30 mm [7-3/32 x 4-23/32 x 1-3/16 in]	
Sound Pressure Level		The A-weighted sound pressure level is below 70 dB.	

*1 Not for use with a generic DC power supply device. Use the power supply unit for transmission cable (PAC-SC51KUA etc.) by Mitsubishi.

*2 "Power consumption coefficient" is a coefficient to calculate the relative power consumption of the devices that receive power through the M-NET transmission cable.

Refer to the note at the end of Chapter 1-5 "System diagram" in the Installation Manual.

Bu uyarının içeriđi sadece Türkiye’de geçerlidir.

- Şirketimizdeki geliştirme faaliyetlerinden dolayı ürün özelliklerinin, haber verilmeksizin değıştirilme hakkı tarafımızda saklıdır.
- Anma değeri için TS EN 14511 / TS EN 14825 deki iklim şartları ile tarif edilen koşullar esas alınmıştır.
- İç ve dış ortam sıcaklıklarının standartlarda esas alınan değeri dışına çıkması durumunda klimanızın ısıtma ve soğutma kapasitelerinin etkilenmesi doğaldır.
- Ürünün üzerinde bulunan işaretlemelerde veya ürünle birlikte verilen diğer basılı dokümanlarda beyan edilen değeri, ilgili standartlara göre laboratuvar ortamında elde edilen değeri. Bu değeri, ürünün kullanım ve ortam şartlarına göre değışebilir.
- Satın almış olduğunuz ürünün kullanım ömrü 10 yıldır. Bu, ürünün fonksiyonunu yerine getirebilmesi için gerekli yedek parça bulundurma süresidir.

Ürünün montajı için Mitsubishi Electric Turkey Elektrik Ürünleri A.Ş. yetkili servisine / bayisine başvurunuz.

Servis İstasyonları ve Yedek Parça Temini :

Cihazınızın bakım, onarım ve yedek parça ihtiyaçları için klimanızı satın aldığınız yetkili satıcıya başvurunuz. Yetkili Servislerimizin listesine URL:<http://klima.mitsubishielectric.com.tr> adresinden veya 444 7 500 numaralı telefondan ulaşabilirsiniz.

Ünitenin ihtiyaç duyacağı bakım ve onarım parçaları 10 yıl boyunca üretilecektir.

İthalatçı Firma:

Mitsubishi Electric Turkey Elektrik Ürünleri A.Ş.

Şerifali Mah. Kale Sk. No:41 34775 Ümraniye, İstanbul / Türkiye

Tel: + 90 216 969 25 00 Faks: + 90 216 661 44 47

klima@tr.mee.com

URL:<http://klima.mitsubishielectric.com.tr>

SİCİL NO : 845150

MERSİS NO : 0 621047840100014

Üretici Firma:

Mitsubishi Electric Corporation (Head Office)

Tokyo Building 2-7-3, Marunouchi, Chiyoda-ku, Tokyo 100-8310, Japan

Tel: +81 (3) 3218-2111

www.mitsubishielectric.com

This product is designed and intended for use in the residential,
commercial and light-industrial environment.

This product at hand is based on the following EU regulations:

- Electromagnetic Compatibility Directive 2014/30/EU
- Restriction of Hazardous Substances 2011/65/EU

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

MANUFACTURER: MITSUBISHI ELECTRIC CORPORATION Air-conditioning & Refrigeration Systems Works
5-66, Tebira 6 Chome, Wakayama-city, 640-8686, Japan

WT06980X04